



PIONIER

T I M E P I E C E S

MADE IN GERMANY

INSTRUCTION BOOKLET



PIONIER

MADE IN GERMANY

INSTRUCTION MANUAL
MODEL: ARUBA DIAMOND
REF. GM 507

BEFORE WEARING THE WATCH - ATTENTION

- Wind the watch 30 times clockwise
- To adjust time pull crown to position C
- Before setting the date (position B), make sure the watch hands are set between 6 am and 6 pm
- **NEVER adjust the date when the watch hands are between 9 pm and 3 am!**
- The accuracy of a mechanical automatic movement can not be compared with that of a quartz battery watch
- In order to obtain an accurate time, the watch should be

worn at least 12 hours a day

- If the watch is not worn for more than 42 hours, make sure to wind the watch's crown 30 times in clockwise motion before wearing it.
- Keep the watch away from high temperatures and strong magnetic fields to prevent any influence on the running accuracy.
- Please consider that the specification of the water resistance is only valuable for the new watch, not being a permanent condition.

So please avoid excessive contact with water.

PIONIER WARRANTY

The best German designs were used in the manufacturing of this masterpiece. Pionier uses only modern techniques and latest watchmaking machineries.

Pionier infuses tradition and modern in every watch that is why each timepiece has a 24 months international warranty. This covers any mechanical manufacturing defects under normal wear.

The warranty does not cover tampering accidents, misuse or damages, no matter how they were caused.

The warranty does not cover band, glass, and damages caused by a third party.

MAINTENANCE

- Clean your watch with a dry or with a dampened cloth
- The watch must not come in contact with saltwater, soap, shampoo or strong cleaning agents such as gasoline, cleaning spray, colours, adhesive, chemicals etc.
- Keep the watch clear of strong magnetic fields. You could magnetize your watch inadvertently and cause erratic gear behavior.
The watch may also stop entirely!
- Avoid extreme temperatures. Moving between excessive cold and hot temperatures can cause the parts to expand or contract, which may cause damage to the whole unit.
- Harmful and sharp objects and harsh surfaces will scratch your watch. We recommend avoiding them.

'Scratch resistant' does not mean, 'scratch proof'.

TECHNICAL SPECIFICATIONS - MODEL „ARUBA“

- Dial set with 6 Diamonds - Size 1-1,1 mm
- Automatic movement with 20 Jewels
- Sapphire coated mineral glass
- Genuine cow leather band
- Stainless steel case
- Size approx. 44 mm without crown
- Water Resistant 3 ATM
- Original Pionier luxury packaging
- 24 months international warranty
- Made in Germany



Pos A

Hand winding mode

Pos B

Date setting mode

Pos C

Time setting mode



Pos 0

Handaufzug-Modus

Pos 1

Ziehen Sie die Krone auf Pos1 um das Datum einzustellen

Pos 2

Ziehen Sie die Krone auf Pos2 um die Zeit einzustellen

BESCHREIBUNG - MODELL „ARUBA“

- Zifferblatt mit 6 Diamanten besetzt - Größe 1-1,1mm
- Automatikwerk mit 20 Lagersteinen
- Gehäusedurchmesser 44mm (ohne Krone)
- Echtlederarmband mit Logogravur
- Edelstahlgehäuse
- Saphirbeschichtetes Mineralglas
- Edelste Detailverarbeitung
- Wasserdicht - 3 atm druckgeprüft
- Incl. Pionier Etui & Garantiekarte
- Made in Germany

DIE INBETRIEBNAHME

- Ziehen Sie Ihre Uhr an der Krone mit ca. 30 Umdrehungen auf.
- Stellen Sie die Zeiger mit Hilfe der Krone auf die gültige Tageszeit
- Benutzen Sie **niemals** die Datumsschnellschaltung zwischen 21:00 Uhr und 3:00 Uhr
- Sie sollten die Uhr mindestens über 12 Stunden täglich tragen, damit die Zugfeder genug Reserve für die Ruhezeit aufbauen kann
- Setzen Sie Ihre Uhr weder hohen Temperaturen noch starken Magnetfeldern aus, da diese Einfluss auf die Ganggenauigkeit haben
- Die Ganggenauigkeit einer Automatikuhr ist naturgemäss nicht mit einer Quarzuhr vergleichbar. Geringe Gangabweichungen von bis zu 30sec am Tag sind normal

GARANTIE

Pionier gewährt ab dem Kaufdatum eine Garantie von zwei (2) Jahren gemäß den geltenden Garantiebedingungen. Sie erstreckt sich auf Materialdefekte und Verarbeitungsfehler.

Die Herstellergarantie bezieht sich nicht auf:

- Gehäuse, Uhrglas, Verschluss oder Armband
- Schäden die durch unsachgemäße Behandlung, Fahrlässigkeit, Unfall oder normale Abnutzung entstehen
- Reparaturen an Uhren, die nicht bei einem autorisierten Pionier-Händler gekauft wurden

Die Garantie erlischt, wenn die Uhr durch Umstände beschädigt wird, die nicht auf Materialdefekte oder Verarbeitungsfehler zurückzuführen sind.

PFLEGE IHRER UHR

- Reinigen Sie Ihre Uhr mit einem trockenen oder leicht angefeuchtetem Tuch
- Die Armbanduhr nicht mit Salzwasser, Seifenlauge oder starken Lösungsmitteln wie Benzin, Reinigungssprays, Fleckentfernern, Farben, Kleber usw. in Kontakt bringen
- Diese Uhr enthält Präzisionsteile, daher darf der Gehäuseboden nur in einer autorisierten Fachwerkstatt geöffnet werden.
- Wenn Sie die Armbanduhr nicht tragen, bewahren Sie diese an einem trockenen Ort auf

ENJOY YOUR DAILY LIFE WITH YOUR TIMEPIECE

WIR WÜNSCHEN IHNEN VIEL FREUDE MIT
IHRER UHR



PIONIER
T I M E P I E C E S
MADE IN GERMANY

www.pionierwatches.com

info@pionierwatches.com