



PIONIER

TIMEPIECES | GERMANY

INSTRUCTION MANUAL

GM-518 | BOSTON

SPECIFICATIONS

Model	Boston
Manufactured	Made in Germany
Reference	GM-518
Movement	Automatic with 22 ruby jewels
Dimension	Size approx. 44mm without crown
Sub-Dial	24 hour indication
Glass	Sapphire coated
Case	Stainless steel 5 microns (316L)
Specials	Sun & moon phase
Clasp/Buckle	Deployment
Water-Resistant	3 ATM
Warranty	2-year warranty



MAINTENANCE

- Clean your watch with a dry or dampened clothe.
- The watch must not come in contact with saltwater, any cleaning agents, chemicals etc.
- Keep the watch clear of strong magnetic fields. You could magnetize your watch inadvertently and cause erratic gear behavior.
- Avoid extreme temperatures. Moving between excessive cold and hot temperatures can damage the parts to expand or contract.
- Avoid contact with water. The specification of the water resistance is only accurate for the new watch, not being a permanent condition.
- This timepiece contains precision original parts. Only Pionier authorized specialized agents can open the case of the watch.
- Harmful and sharp objects and harsh surfaces will scratch your watch. 'Scratch resistant' does not mean, 'scratch proof'.

ATTENTION

- The accuracy of a mechanical automatic movement can not be compared with that of a quartz battery watch.
- Slight differences of +/- 20 seconds per day are normal.
- In order to obtain an accurate time, the watch should be worn at least 6 hours a day.
- If the watch is not worn for more than 42 hours, wind the watch by turning the crown clockwise 30 times.



PFLEGE DER UHR

- Reinigen Sie Ihre Uhr mit einem trockenen oder leicht angefeuchteten Tuch.
- Die Uhr nicht mit Salzwasser, Seifenlauge oder starken Lösungsmitteln wie Benzin, Fleckentfernern, Farben, Kleber usw. in Kontakt bringen.
- Halten Sie die Uhr von starken Magnetfeldern fern. Sie könnten Ihre Uhr magnetisieren und ein unregelmäßiges Gangverhalten verursachen.
- Vermeiden Sie extreme Temperaturschwankungen.
- Vermeiden Sie den Kontakt mit Wasser. Die Angabe der Wasserbeständigkeit gilt nur für die neue Uhr und ist kein dauerhafter Zustand.
- Diese Uhr enthält Präzisionsteile, daher darf der Gehäuseboden nur in einer autorisierten Fachwerkstatt geöffnet werden.
- Halten Sie die Uhr von scharfen Gegenständen und rauen Oberflächen fern, denn damit zerkratzen Sie die Uhr.

INFORMATION

- Die Genauigkeit eines mechanischen Automatikwerks kann nicht mit der einer Quarzbatterieuhr verglichen werden.
- Geringe Unterschiede von +/- 20 Sekunden pro Tag sind normal.
- Um eine genaue Uhrzeit zu erhalten, sollte die Uhr mindestens 6 Stunden am Tag getragen werden.
- Wenn die Uhr länger als 42 Stunden nicht getragen wird, ziehen sie die Uhr auf, indem Sie die Krone 30 mal im Uhrzeigersinn drehen.



USAGE



24 hours

A ↔ B
Pos. A
Hand winding mode
Pos. B
Time setting mode



BEDIENUNG



24h Anzeige

A ↔ B
Pos. A
Handaufzug-Modus
Pos. B
Zeiteinstell-Modus



QUALITY

The best German designs were used in the manufacturing of this masterpiece. Pionier uses only modern techniques and the latest watchmaking machinery. The production of these timepieces is very limited in number and all watches are individually hand-assembled. This timepiece offers pure artisanal craftsmanship.

WARRANTY

Each timepiece has a 24 months international warranty and it covers any mechanical manufacturing defects under normal wear. The warranty does not cover tampering accidents, misuse or damages, no matter how they were caused. The warranty does not cover band, glass, and damages caused by a third party.



QUALITÄT


Unsere Pionier Uhren sind wahre Meisterwerke, da jede einzelne Uhr per Hand montiert wird. Wir verarbeiten einzigartige Uhrwerke mit einem ausgefallenen Design. Die Produktion dieser Uhr ist limitiert.

GARANTIE

Pionier gewährt ab dem Kaufdatum eine Garantie von 24 Monaten gemäß den geltenden Garantiebedingungen. Sie erstreckt sich auf Materialdefekte und Verarbeitungsfehler.



DEPLOYMENT BUCKLE




Steps:

1. Open buckle upward.
2. Put strap inside buckle.
3. Put buckle pin in desired hole.
4. Close buckle downward.



BANDVERSTELLUNG



Schritte:

1. Kleine Schließe öffnen
2. Band durch die geöffnete Schließe ziehen
3. Kleinen Stift in das passende Loch führen.
4. Schließe wieder zuklappen



Enjoy your daily life with your new timepiece.

 Pioneer Watches

 pionierwatches

 www.pionierwatches.com